




ASSEMBLY INSTRUCTION

ARMOY 2 DRAWER BEDSIDE

ITEM CODE 85158






Imported by Amart Furniture Pty Ltd.Qld.Brisbane Australia.
For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

 ALLOW 45 MINUTES	 x 2 2 PEOPLE REQUIRED
 ⊕ ADDITIONAL TOOLS REQUIRED	

⚠ WARNING		
		<p>Children have died from furniture tipover.</p> <ul style="list-style-type: none">• ALWAYS secure it with an anchor device.• NEVER allow children to stand, climb or hang on drawers, doors, or shelves.• NEVER open more than one drawer at a time.• Place heavy items down low <p>NEVER put a TV on this furniture </p> <p><small>This is a permanent label. Do not remove!</small></p>


CAM Lock and Pins

step 1


HOW TO USE CAM LOCK FASTENERS

To assemble this product hardware called Cam Lock Fasteners are used.
The below is information on how these work.

Cam Locks are fasteners used to join two boards together,
usually the edge of one board(A) to the flat side of another board(B)



Ensure that you use the correct images that are representative
of the hardware used in the product




step 2

To use Cam Lock Fasteners

The Cam Pin is inserted into the flat side of a board,
it is important that:


- * The cam pin is kept vertical and is not put in on an angle
- * Cam Pin is inserted up to the collar
 - * Too far and it won't catch the Cam Lock (Do not Over Tighten)
 - * Not enough and the resulting product won't be stable



step 3

To use Cam Lock Fasteners


Now fit the hole in the edge of the joining board over the Cam Pin



step 4

To use Cam Lock Fasteners

The Head of the Cam Pin will be visible in the large hole on the side of the joining board



To use Cam Lock Fasteners

Notice the Cam Lock has a "C" Shaped back An Arrow or +/- signs on the front, indicated the open section on the back of the Cam Pin




Cam Lock

step 5

To use Cam Lock Fasteners


In sert the Cam Lock into the large hole so the opening of the "C" fits over the head of the Cam Pin.You must ensure that the Cam Lock is pushed to the bottom of the hole to catch the top of the Cam Pin




step 6

To use Cam Lock Fasteners













Use a flat screwdriver to turn the Cam Lock clockwise one half a turn so it Locks onto the head of the Cam Pin.Turn only until it is snug-over-tightening could cause the Cam to bend or break. If it will not turn the full amount,turn the Cam Pin out (counter-clockwise)one full turn,and try the Cam Lock again.



PARTS LIST




C1	Top Panel	C11	Drawer Front Panel
C2	Bottom Rail	C12	Drawer Left Side Panel
C3	Bottom Rail	C13	Drawer Right Side Pane
C4	Left Side Panel	C14	Drawer Back Panel
C5	Right Side Panel	C15	Drawer Front Panel
C6	Back Panel	C16	Drawer Left Side Panel
C7	Back Rail	C17	Drawer Right Side Pane
C8	Front Rail	C18	Drawer Back Panel
C9 X2	Leg	C19X2	Drawer Bottom Panel
C10X2	Leg		

<input type="checkbox"/> A.Cam lock and Cam pin Ø15X35  26PCS	<input type="checkbox"/> B.Dowel Ø8x30  12PCS	<input type="checkbox"/> C.Screw Ø3.5x12  24PCS	<input type="checkbox"/> D.Screw Ø3.5x30  8PCS	<input type="checkbox"/> E.Connector 18x16x10  4PCS	<input type="checkbox"/> F.Screw Ø3x18  4PCS	<input type="checkbox"/> G.Runner  4PCS
<input type="checkbox"/> H.Protect foam Ø35x5mm  4PCS	<input type="checkbox"/> I.GLUE  1PCE	<input type="checkbox"/> J.Safety Bracket Kit  1PCS	<input type="checkbox"/> K.Bolt M6x30  8PCS	<input type="checkbox"/> L.Hex Key 4MM  1PCE		

STEP 1:


Runner slide separately ($G=G1+G2$)

Carefully pull out the runner slide ($G2$) and press plastic clip to fully separate runner slide as diagram shown




STEP 2:


Use Phillips Head Screwdriver to insert the Cam Pin(A) and Dowel(B) to the Top Panel(C1) and Left side Panel(C4) and Right Side Panel(C5) and Drawer Front Panel(C11&C15) and Back Rail(C7). And use Phillips Head Screwdriver to attach the Runner(G1) to the Left side Panel(C4) and Right Side Panel(C5) with Screw (C). Dowel with Glue(I).




STEP 3: Use Hex Key(L) to attach the Side Panel(C4&C5) to the Leg(C9,C10) with Bolt(K), Use Phillips Head Screwdriver to assemble Bottom Rail(C3) to the Back Rail(C7), turn the Cam lock to the Cam Pin. Dowel with Glue(I), Stick the Protect Foam(H) to the bottom of the Leg(C9,C10).




STEP 4: Use Phillips Head Screwdriver to assemble Back Rail(C7) and Bottom Panel(C2,C3) and Front Rail(C8) to the Left Side Panel(C4) and Right Side Panel(C5), lock the Cam Lock to the Cam Pin.




STEP 5: Insert the Back Panel(C6) to the Groove.Use Phillips Head Screwdriver to assemble Top Panel(C1) to the Side Panel(C4,C5).Lock the Cam Lock to the Cam Pin.




STEP 6: Use a Phillips Head Screwdriver to assemble Connector(E) to the Back Corner with Screw(F).




STEP 7: Use a Phillips Head Screwdriver to attach Runner(G2) to the Panel (C12,C13) with Screw(C).assemble Panel (C12,C13) to the Drawer Back Panel(C14) with Screw(D).




STEP 8: Insert the Drawer Bottom Panel(C19) to the groove,Use a Phillips Head Screwdriver to assemble Panel(C12,C13) to the Drawer Front Panel (C11) with Cam Lock(A).



STEP 9: Use a Phillips Head Screwdriver to attach Runner(G2) to the Panel (C16,C17) with Screw(C).assemble Panel (C16,C17) to the Drawer Back Panel(C18) with Screw(D).




STEP 10: Insert the Drawer Bottom Panel(C19) to the groove,Use a Phillips Head Screwdriver to assemble Panel(C16,C17) to the Drawer Front Panel (C15) with Cam Lock(A).



STEP 9:
Insert the drawers into the body.

Please slot in the drawer with
TIPPING WARNING STICKER
inside is slotted to top layer.



SAFETY BRACKETS INSTRUCTIONS

This furniture poses a tipping risk and as such must be secured to a wall using the provided tipping kit.

1. Attach one Mounting Plate to the wall with the Large Screws. Make sure to attach the Mounting Plate into a stud. If mounting into brick or masonry you will need to acquire wall anchors. Please enquire with your local hardware supplier for appropriate fixings.
2. Attach the second Mounting Plate to the furniture frame with the Short Screws.
3. Move the furniture to its final position. Thread a Wall Strap through the both Mounting Plates and tighten until snug. Do not over tighten.
4. Make sure that the Mounting Plates are firmly attached to the wall and furniture and that the Wall Strap is snug.

HARDWARE



Mounting Plate x 2




Wall Strap x 1




Large Screw x2



Small Screw x2



Assembly is complete



Note -

Do not drag the furniture as this may cause damage to the legs. Instead, use 2 persons to lift carefully from either end.

General Product Care

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.