




ASSEMBLY INSTRUCTION  
ADEONA QUEEN BED  
ITEM CODE 83996








Imported by Amart Furniture Pty Ltd, Brisbane ,Qld Australia.  
For any assistance with assembly or for missing parts please phone Amart Furniture, Customer Service Free call 1800 351 084

## PRE-ASSEMBLY PREPARATION

### Before you start:


1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

	
ALLOW 60 MINUTES	2 PEOPLE REQUIRED
	
TOOLS REQUIRED	












We recommend using a screwdriver to put this item together. However if you choose to use a power drill it must be used on LOW SPEED (LOW TORQUE) as too much pressure could damage the product

# PARTS LIST




1	HEADBOARD
2	HEADBOARD LEG
3	HEADBOARD LEG
4	HEADBOARD BOTTOM BAR
5	SIDERAIL


6	FOOTBOARD
7	CENTRE RAIL
8	SUPPORT LEGS
9	SLATS

A. M6X32mm  AX10	B. M8X32mm  BX18	C. M8XØ18  CX18	D.  DX12	E. M5  EX1
F. M4X28mm  FX26	G. M8XØ18  GX10	H. M4  HX1	I. M4X35mm  IX2	


# 1.




- Attach headboard leg (2) (3) to headboard(1) with flat washer (G) and bolt (A)
- Note: Do not tighten the bolts.




# 2.




- Fix the headboard leg (2) (3) to headboard side board with flat washer (G) and bolt (A)
- After adjusting the position of the legs, tighten all bolts including those in the step 1 with allen key (H)



# 3.







- Attach headboard bottom bar(4) to headboard leg (2) (3) with flat washer (C) and bolt (B)
- Tighten all bolts with allen key (E)




**Note: The headboard bottom bar needs to be flipped 180° and the opening of the wooden bracket should be kept upward.**







# 4.

<p>B. M8X32mm</p>  <p>BX6</p>	<p>C. M8XØ18</p>  <p>CX6</p>	<p>D.</p>  <p>DX6</p>	<p>E. M5</p>  <p>EX1</p>
--	---	--	---


- Attach the siderail (5) to headboard leg(2) and footboard (6) with flat washer (C), lock washer (D) and bolt (B)
- Note: Do not tighten the bolts.







# 5.

<p>B. M8X32mm</p>  <p>BX6</p>	<p>C. M8XØ18</p>  <p>CX6</p>	<p>D.</p>  <p>DX6</p>	<p>E. M5</p>  <p>EX1</p>
--	---	---	---


- Attach the siderail (5) to headboard leg(3) and footboard (6) with flat washer (C) , lock washer (D) and bolt (B)
- Tighten all bolts with allen key (E)



# 6.

<p>B. M8X32mm</p>  <p>BX2</p>	<p>C. M8XØ18</p>  <p>CX2</p>	<p>E. M5</p>  <p>EX1</p>	<p>I. M4X35mm</p>  <p>IX2</p>
--	---	--	--

- Attach support legs (8) to centre rail (7) with flat washer (C) and bolt (B)
- Attach centre rail(7) to headboard bottom bar (4) and footboard (6) with screws (I)
- Tighten with allen key (E)




# 7.


F. M4X28mm



FX26



- Attach slats (9) to siderails (5) using screws (F)。
- Use Screwdriver or Power Drill on Low Speed.






ASSEMBLY IS COMPLETE

**CAUTION**

Always Lift Your Bed When Moving /Relocating -  
Do Not Drag. Dragging Can Cause The Centre  
Support Legs To Bend/Break.



# Care and maintenance



As our timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time