


ASSEMBLY INSTRUCTION

KENORA BUNK BED

ITEM CODE : 85255

Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.

For any assistance with assembly or for missing parts please phone
Amart Furniture Pty Ltd Customer Service Free call 1800 351 084






Imported by Amart Furniture Pty Ltd, Qld, Brisbane Australia.
For any assistance with assembly or for missing parts please phone
Amart Furniture Pty Ltd, Customer Service Free call 1800 351 084

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.

	
ALLOW 45 MINUTES	2 PERSON REQUIRED
	
ADDITIONAL TOOLS REQUIRED	NO POWER DRILL

WARNING :

TOP BUNKS AND ELEVATED BEDS ARE DANGEROUS AND ARE NOT RECOMMENDED FOR CHILDREN UNDER THE AGE OF 9

Falls from elevated beds can be fatal and deaths have occurred where children have fallen from elevated beds. This is relevant for all ages. The risk is greater for younger children.


The risk injury or death from a fall from an elevated bed compared to a non-elevated bed is :

- 10 x greater for 7-8 year olds
- 7 x greater for 9-10 year olds
- 3 x greater for 11-12 year olds

TO HELP PREVENT serious or fatal injuries from entrapment of falls :

- Use the correct size mattress as specified.
- It must be at least 6.25" (160mm) below upper edge of guardrails.
- Follow written instructions with this bed.
- Use guardrails on both sides of upper bunk.
- Prohibits horseplay on or under bed.
- Check the bunk bed periodically to ensure that the guardrail, access device and other components are maintained in the correct position and state of repair and that all connectors are tight.
- Prohibit more than one person on upper bunk.
- WARNING: The upper bunk must be more than 2m from any ceiling fan.


PART LIST



1	TOP HEADBOARD	(X2)	8	SEMI GUARD RAIL	(X2)
2	BOTTOM HEADBOARD	(X2)	9	FULL GUARD RAIL	(X2)
3	UPPER SIDE RAIL (FRONT)	(X1)	10L	LADDER SIDE - L	(X1)
4	UPPER SIDE RAIL (REAR)	(X1)	10R	LADDER SIDE - R	(X1)
5	LOWER SIDE RAIL (FRONT)	(X1)	11	LADDER SLAT	(X2)
6	LOWER SIDE RAIL (REAR)	(X1)	12	WOODEN SLAT (63x927=15)	(X2)
7	GUARD RAIL SUPPORT	(X2)			


HARDWARE LIST (VP 445)

A. PLASTIC DOWEL (M10 x 35MM)




16 PCS

B. JCBC BOLT (M6 x 35MM)




8 PCS

C. JCBC BOLT (M6 x 50MM)




10 PCS

D. JCBC BOLT (M6 x 65MM)



2 PCS

E. JCBC BOLT (M6 x 90MM)



22 PCS

F. JRN NUT (M6 x 13MM)



32 PCS

G. JCN NUT (M6 x 12MM)




2 PCS

H. JCBC W SCREW (M7 x 32MM)




20 PCS

J. CSK C/B SCREW (M4 x 32MM)




51 PCS

K. METAL PIN WITH 2 HOLES (M10 x 80MM)



4 PCS



L. ALLEN KEY (M4 x 60MM)



2 PCS


STEP 1

Insert **Dowels (A)** into Ø10MM holes on **Upper Side Rails (Front) & (Rear)** and **Lower Side Rails (Front) & (Rear)** & **Ladder Slat** by using a Rubber Hammer.




STEP 2

Attach **Upper Side Rails (Front) & (Rear)** to **Top Headboards** by using **Bolts (E) & Nuts (F)**, tighten it up by using an **Allen Key (L)**.



STEP 3


Attach **Lower Side Rails (Front) & (Rear)** to **Bottom Headboards** by using **Bolts (E) & Nuts (F)**, tighten it up by using an **Allen Key (L)**.



STEP 4


Connect both the **Top Bed & Bottom Bed** together by using **Metal Pins (K)**. Screw **Bolts (B)** into Ø14MM holes, tighten it up by using an **Allen Key (L)**.

** Make sure both Upper & Lower Side Rails (Front) with 2 EXTRA HOLES are facing outwards while doing this assembly.*




STEP 5

Attach and secure **Ladder Slats** onto both **Ladder Side (L/R)** by using **Bolts (C)** & **Nuts (F)**, tighten it up by using an **Allen Key (L)**.




STEP 6

Attach **Ladder** onto **Upper Side Rail (Front)** and **Lower Side Rail (Front)** by using **Screws (J)**, tighten it up by using a Crosshead Screw Driver. Secure **Ladder** onto the **Top Footboard** by using **Bolts (D)** and **Nuts (G)**, tighten it up by using **Allen Keys (L)**. Secure **Ladder** onto **Upper Side Rail (Front)** and **Lower Side Rail (Front)** by using **Bolts (C)** and **Nuts (F)**, tighten it up by using an **Allen Key (L)**.



STEP 7


Attach and secure **Guard Rail Supports** onto **Upper Side Rails (Front & Rear)** by using **Screws (H)**, tighten it up by using an **Allen Key (L)**.



STEP 8

Attach and Secure **Wooden Slat** onto **Upper Side Rail** & **Bottom Side Rail** by using **Screws (H)**, tighten it up by using an **Allen Key (L)**.

** Align both **Upper Side Rail** & **Bottom Side Rail** before tightening the screws.*




STEP 9

Using **Screws (J)** to secure all the **Wooden Slat** onto **Upper Side Rail** & **Bottom Side Rail**, tighten it up by using a Crosshead Screw Driver.


Go on to complete the assembly.

** Align both **Upper Side Rail** & **Bottom Side Rail** before tightening the screws.*




STEP 10

Attach and secure **Full Guard Rail** onto **Top Footboard** by using **Bolts (E)** & **Nuts (F)**, tighten it up by using an **Allen Key (L)**. Secure **Guard Rail Support** by using **Screws (H)** into Ø8MM holes on **Full Guard Rail**, tighten it up by using an **Allen Key (L)**.




STEP 11

Attach and secure **Semi Guard Rail** onto **Top Footboard** by using **Bolts (E)** & **Nuts (F)**, tighten it up by using an **Allen Key (L)**. Attach and secure **Semi Guard Rail** onto **Ladder** by using **Bolts (C)** & **Nuts (F)**, tighten it up by using an **Allen Key (L)**. Secure **Guard Rail Support** by using **Screws (H)** into Ø8MM holes on **Full Guard Rail**, tighten it up by using an **Allen Key (L)**.






ASSEMBLY IS COMPLETE



Convertible Feature


This bunk bed is able to convert to 2 single beds. Follow the instructions given.

This assembly must be completed by at least 2 person.




STEP 1 (Conversion)

Unscrew Bolts (C), Bolts (E), Nuts (F) & Screws (H) and detach Semi Guard Rail by using an Allen Key (L).




STEP 2 (Conversion)

Unscrew Bolts (E), Nuts (F) & Screws (H) and detach Semi Guard Rail by using an Allen Key (L).




STEP 3 (Conversion)

Unscrew **Screws (H) & (J)** 8 Slat from Ladder Side to center on **Top Bed** and 4 Slat from Ladder Side to center on **Bottom Bed** by using an **Allen Key (L)** and a Crosshead Screw Driver and detach **Wooden Slat**.




STEP 4 (Conversion)

Unscrew **Screws (H)** by using an **Allen Key (L)** and detach **Guard Rail Supports**.




STEP 5 (Conversion)

Unscrew **Bolts (C), (D) Nuts (F), (G) & Screws (J)** and detach **Ladder** by using an **Allen Key (L)** and a Crosshead Screw Driver.




STEP 6 (Conversion)

Unscrew **Screws (B)** by using an **Allen Key (L)** and unattach **Metal Pins (K)** from assembly as well. Follow that up by separating **Top Bed** from **Bottom Bed**.




STEP 7 (Conversion)

Unscrew **Bolts (E)** and **Nuts (F)** from one side **Top Headboard & Bottom Headboard** by using an **Allen Key (L)**.



STEP 8 (Conversion)


Exchange **Top Headboard & Bottom Headboard**, use **Bolts (E)** and **Nuts (F)** and tighten it up by an **Allen Key (L)**.




STEP 9 (Conversion)

Attach and Secure all the **Wooden Slat** onto **Side Rail** by using **Screws (H) & (J)** , tighten it up by using an **Allen Key (L)** and a Crosshead Screw Driver. Go on to complete the assembly of the convertible feature.

** Align both **Side Rail** before tightening the screws.*



CONVERSION IS COMPLETE



IMPORTANT : PRODUCT CARE FOR TIMBER ITEMS

As our timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique.

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come.

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time.
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care.
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting.
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs.
- Do not allow plastic to come in direct contact with your furniture. Chemicals in plastic or placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time.