



ASSEMBLY INSTRUCTION

HARDY

6 DRAWER DRESSER

ITEM CODE 85477







Imported by JWA Furniture Pty Ltd, Qld, Brisbane Australia
For any assistance with assembly or for missing parts please refer to your receipt




PRE-ASSEMBLY PREPARATION

Before you start:




















1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product.
2. Take care when lifting. Product should be assembled as near as possible to the point of use.
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads.
7. Assembly is to be carried out by a competent adult(s) ONLY.
8. During assembly, children should be kept away from the product due to possible risk to injury.
9. Do not use this item if any components are missing or damaged.
10. Please keep the instructions for future reference.

| | |
|--|---|
|  |  |
| ALLOW 60 MINUTES | PEOPLE REQUIRED |
|  | |
| ADDITIONAL TOOL REQUIRED | |


WARNING



| | | |
|---|---|---|
|  |  | <p>Children have died from furniture tipover.</p> <ul style="list-style-type: none"> • ALWAYS secure it with an anchor device. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heavy items down low <p style="text-align: center;">NEVER put a TV on this furniture</p> <div style="display: flex; align-items: center; justify-content: center;">  </div> <p style="text-align: center; font-size: 0.8em; color: red;">This is a permanent label. Do not remove!</p> |
|---|---|---|

PARTS LIST


| | | | | | |
|--|--|--|--|---|--|
| <div><div>A</div><div>X 54 SETS</div></div> <div><div></div><div></div><div></div></div> <div><div>A1</div><div>A2</div><div>A3</div></div> <div><div>MINIFIX</div></div> | <div><div>B</div><div>X 61</div></div> <div><div></div></div> <div><div>WOOD DOWEL</div><div>M8 X 30</div></div> | <div><div>C</div><div>X 4</div></div> <div><div></div></div> <div><div>M6 X 50MM</div><div>CSK CAP</div><div>WOOD SCREW</div></div> | <div><div>D</div><div>X 1</div></div> <div><div></div></div> <div><div>ALLEN KEY M4</div></div> | <div><div>E</div><div>X 68</div></div> <div><div></div></div> <div><div>M3.5 X 16MM</div><div>C.B SCREW</div></div> | |
| <div><div>F</div><div>X 24</div></div> <div><div></div></div> <div><div>M4 X 20MM</div><div>C.B SCREW</div></div> | <div><div>G</div><div>X 10</div></div> <div><div></div></div> <div><div>M4 X 25MM</div><div>C.B SCREW</div></div> | <div><div>H</div><div>X 26</div></div> <div><div></div></div> <div><div>M4 X 38MM</div><div>C.B SCREW</div></div> | <div><div>I</div><div>X 2</div></div> <div><div></div></div> <div><div>FLAT</div><div>WASHER M6</div></div> | <div><div>J</div><div>X 18</div></div> <div><div></div></div> <div><div>5/8 NAIL</div></div> | <div><div>K</div><div>X 6</div></div> <div><div></div></div> <div><div>5/8 PVC</div><div>NAIL LEG</div></div> |
| <div><div>L</div><div>X 6</div></div> <div><div></div></div> <div><div>HANDLE 209</div><div>KNOB</div></div> | <div><div>M</div><div>X 2</div></div> <div><div></div></div> <div><div>WALL PLUG</div></div> | <div><div>N</div><div>X 2</div></div> <div><div></div></div> <div><div>L BRACKET</div><div>MOUNTING</div></div> | <div><div>O</div><div>X 12</div></div> <div><div></div></div> <div><div>PVC</div><div>BLOCK</div></div> | <div><div>P</div><div>X 6 SETS</div></div> <div><div></div><div></div></div> <div><div>P1 (L/R)</div><div>P2 (L/R)</div></div> <div><div>12" DRAWER SLIDE</div></div> | |

| | | |
|----|--------------------|-------|
| 1 | TOP PANEL | 1 PC |
| 2 | SIDE PANEL (L) | 1 PC |
| 3 | SIDE PANEL (R) | 1 PC |
| 4 | CENTER PANEL | 1 PC |
| 5 | TOP BONE | 1 PC |
| 6 | SIDE BONE | 2 PCS |
| 7 | BOTTOM BONE | 1 PC |
| 8 | LEG PANEL (FRONT) | 1 PC |
| 9 | LEG PANEL (BACK) | 1 PC |
| 10 | BOTTOM BAR (FRONT) | 1 PC |

| | | |
|----|-------------------|-------|
| 11 | BOTTOM BAR (BACK) | 1 PC |
| 12 | BACK PANEL (TOP) | 1 PC |
| 13 | BACK PANEL | 1 PC |
| 14 | DRAWER FRONT (L) | 3 PCS |
| 15 | DRAWER FRONT (R) | 3 PCS |
| 16 | DRAWER SIDE (L) | 6 PCS |
| 17 | DRAWER SIDE (R) | 6 PCS |
| 18 | DRAWER BACK | 6 PCS |
| 19 | DRAWER BOTTOM | 6 PCS |
| 20 | DRAWER BONE | 6 PCS |




x3



x3


STEP 1:

- Insert hardware **A1** onto panel (4).
(Repeat 2 times.)
- Insert hardware **A2** onto panel (1).
(Repeat 12 times.)
- Insert hardware **B** onto panel (4) and (5).
(Repeat 4 times.)
- Assemble hardware **N** into panel (1) by using hardware **E** and **I**.
(Repeat 2 times.)




STEP 2:

- Insert hardware **A1** onto panel (2), (3) and (5).
(Repeat 14 times.)
- Insert hardware **A2** onto panel (2) and (3).
(Repeat 8 times.)
- Insert hardware **B** onto panel (2), (3) and (5).
(Repeat 12 times.)




STEP 3:

- Insert hardware **A2** onto panel (6), (7) and (9).
(Repeat 10 times.)
- Insert hardware **B** onto panel (9).
(Repeat 7 times.)




STEP 4:

- Insert hardware **A1** onto panel (10), (11) and (12).
(Repeat 14 times.)
- Insert hardware **B** onto panel (10), (11) and (12).
(Repeat 14 times.)




STEP 5:

- Assemble hardware **O** onto panel **(2)** and **(3)** by using hardware **F**.
(Repeat 2 times for each hardware.)




STEP 6:

- Fix hardware **P1 (L/R)** into hardware **O** with hardware **E**.
(Repeat 2 times for each hardware.)




STEP 7:

- Fix hardware **P1 (L)** into panel **(4)** with hardware **E**.
(Repeat 3 times for each hardware.)




STEP 8:

- Fix hardware **P1 (R)** into panel **(4)** with hardware **E**.
(Repeat 3 times for each hardware.)




STEP 10:

- Attach panel (6) to panel (2) and (3).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 6 times.)




STEP 11:

- Attach panel (5) to panel (1).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 4 times.)




STEP 12:

- Attach panel (2) and (3) to panel (9), (10), (11) and (12).
- Attach panel (7) to panel (10).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 12 times.)




STEP 13:

- Assemble panel (8) with panel (7) by using hardware G.
- (Repeat 4 times.)




STEP 14:

- Connect panel (4) to panel (10), (11) and (12) by using hardware C and D.
(Repeat 4 times.)




STEP 15:

- Attach panel (1) to panel (2), (3), (4) and (12).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
(Repeat 8 times.)




STEP 16:

- Assemble panel (13) to entire body with hardware J.
(Repeat 18 times.)



STEP 17:

- Hit hardware K into bottom of panel (2), (3), (8) and (9).
(Repeat 6 times.)



STEP 18:


Mark the holes on the wall by using the pencil (not supplied).
(Repeat 2 times.)

You can mark these points in as below:

1) Move the Dresser back to the wall.


Mark two points same height as Dresser on the wall.

2) Measure the height of the hole on panel (12) with ruler/measuring tape and mark on wall to keep them accurate and same height.




STEP 19:

Use the power drill to drill the marking point on the wall.




STEP 20:

Hit hardware **M** into the wall.
(Repeat 2 times.)




STEP 21:

- Assemble hardware **M** to **N** by using hardware **H**.
(Repeat 2 times.)




STEP 22:

- Insert hardware A1 onto panel (16), (17) and (20).
(Repeat 24 times.)
- Insert hardware A2 onto panel (14), (15) and (18).
(Repeat 24 times.)
- Insert hardware B onto panel (16) and (17).
(Repeat 24 times.)




STEP 23:

- Fix hardware L onto panel (13) by using hardware G.
(Repeat 1 times for each hardware.)




STEP 24:

- Attach panel (14) to panel (16) and (17).
- Attach panel (15) to panel (16) and (17).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 12 times.)




STEP 25:

- Insert the panel (19) along the slot.
- (Repeat 6 times.)




STEP 26:

- Attach panel (20) to panel (14) and (15).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 6 times.)




STEP 27:

- Attach panel (20) to panel (18).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 6 times.)




STEP 28:

- Assemble panel (16) and (17) to panel (18) by using hardware H.
(Repeat 24 times.)




STEP 29:

- Assemble hardware P2 (L/R) to panel (14) and (15) by using hardware D.
(Repeat 3 times for each hardware.)




STEP 30:

- Put all the drawer in place along the drawer slides.



ASSEMBLY IS COMPLETE



CARE AND MAINTENANCE

To protect your furniture, we suggest the following :

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under window.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause server finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.

NOTE: If the above care advise is not adhered to your product warranty may become void.