




ASSEMBLY INSTRUCTION VINCENTIO QUEEN BED ITEM CODE 85549




Imported by Amart Furniture Pty Ltd. Qld. Brisbane Australia.
For any assistance with assembly or for missing parts please phone Amart Furniture
Customer Service Free call 1800 351 084

85549

PRE-ASSEMBLY PREPARATION

Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads




WARNING




















Do not allow children to play on this mechanised furniture or operate the mechanism. Ensure that the mattress and lift mechanism has been returned to the lowered position before lying or sitting on the mattress. Always ensure that your body is clear of the lift mechanism when lifting and lowering the mechanism

PARTS LIST




C1	Headboard	C9	Support Panel
C2	Footboard	C10x12	Bottom Rail
C3	Footboard Rail	C11x8	Bottom Rail
C4	Left Side Rail	C12x8	Bottom Panel
C5	Left Side Bottom Rail	C13x2	Handle
C6	Right Side Rail	C14	Slats
C7	Right Side Bottom Rail	C15	Leftside Gas Lift
C8	Support Panel	C16	Rightside Gas Lift


A. Cam lock and Cam pin Ø15x35	<input type="checkbox"/>	B. Dowel Ø8X30	<input type="checkbox"/>	C. Bolt M6x14	<input type="checkbox"/>	D. Bolt M8x20	<input type="checkbox"/>	E. Bolt M8x50	<input type="checkbox"/>	F. Bolt M8x80	<input type="checkbox"/>	G. Cover Ø38	<input type="checkbox"/>
													
50PCS		38PCS		8PCS		24PCS		6PCS		4PCS		4PCS	
H. Half Round Nuts M8	<input type="checkbox"/>	I. Hexagonal Nuts M8	<input type="checkbox"/>	J. Wrench M14	<input type="checkbox"/>	K. Bolt M6x45	<input type="checkbox"/>	L. Glue	<input type="checkbox"/>	M. Hex Key 4MM	<input type="checkbox"/>	N. Hex Key 5MM	<input type="checkbox"/>
													
4PCS		10PCS		1PCE		4PCE		1PCE		1PCE		1PCE	
O. Protect foam 20x14x5mm	<input type="checkbox"/>	P. Corner Support 171x171x34mm	<input type="checkbox"/>	Q. L. Corner Plate 50x50x216mm	<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>		<input type="checkbox"/>
													
40PCS		2PCS		2PCS									

85549

STEP 1: Use a Phillips Head Screwdriver to attach Cam Pin(A) and Dower(B) to Panel(C4,C5,C6,C7), Stick the Protect Foam (O) to the Panel(C5,C7). Dowel with Glue(L).




STEP 2: Use a Phillips Head Screwdriver to attach Cam Pin(A) to Panel(C1,C2,C3,C11). Stick the Protect Foam(O) on Panel(C1,C3).




85549


STEP 3: Use a Phillips Head Screwdriver to assemble Panel(C4) to Panel(C5) with Cam Lock(A).assemble Panel(C6) to the Panel(C7) with Cam Lock(A).assemble Panel(C2) to Panel(C3) with Cam Lock(A).




STEP 4: Assemble Support Panel(C9) to the Support Panel (C8).Stick the Protcet Foam(O) to the Panel(C9).



STEP 5: Use Phillips Head Screwdriver to assemble Support Panel(C9) to the Side Rail(C4,C6) with Cam Lock(A).




STEP 6: Use a Phillips Head Screwdriver to assemble Side Panel(C4,C6) and Support Panel(C8) to the Headboard(C1) and Footboard(C2) with Cam Lock(A). Use Hex Key(N) to assemble Corner Plate(Q) to the Headboard(C1) and Side Panel (C4,C6) with Bolt(D). Use Wrench(J) to assemble the Panel(C4,C5) to the Footboard(C2) with Bolt(F) and Half Round Nut(H) and Hexagonal Nut(I), Insert the Cover(G) to the holes.




85549


STEP 7: Use Hex Key(M) to assemble Corner Support(P) to the Footboard(C2) and Side Rail(C4,C6) with Bolt(C).



STEP 8: Use a Phillips Head Screwdriver to insert Cam Pin(A) to the Bottom Rail(C11). Insert Dowel(B) to the Bottom Rail(C11) with Glue(O), assemble Bottom Rail (C10) to the Bottom Rail(C11) with Cam Lock(A). Dowel with Glue(L).




STEP 9: Insert the Bottom Frame to the Bed




STEP 10:

Use Hex Key(M) to assemble the Lifting Handle(C13) to the Slat(C14) with Bolt (K)




STEP 11:

Use Hex Key(N)to assemble the Gas(C15,C16)to the Siderail(C4,C6)with Bolt(D).




STEP 12:

Use Hex Key(N)and Wrench(J)to assemble the Gas(C15,C16)to the Slat (C14)with Bolt (E)and Hexagonal Nuts(I) .




SAFETY CAUTION WARNING

Please always lock the safety lock mechanism while the bed base is in lifting position.
Unlock it before you want to put the bed base back into normal position.




UNLOCK POSITION



LOCK POSITION

STEP 13:


Insert the Bottom Panel(C12)to the Bottom Rail.



Assembly is complete

IMPORTANT NOTE:

PINCH HAZARD: BEWARE OF YOUR FINGERS WHEN LIFTING AND LOWERING THE MECHANISM



IMPORTANT NOTE:

Once the bed is positioned and the support legs are adjusted to touch floor , the slats can then be laid down and secured before putting on the mattress. DO NOT push or pull the bed if there is a need for re-positioning as this may result in broken support legs for the centre rail.

Product Care for Timber Items

As our timber is supplied from sustainable forests there will be natural variations in surface texture and grain like knots, mineral streaks and sap runs that may affect the finish. These differences in character are not defects, but distinctions that make each piece of furniture unique

Our furniture is built to last. Following these steps for basic care should protect your investment for years to come

- Dust frequently with a clean damp lint-free cloth. This will help remove abrasive build up which can damage a finish over time
- Do not place hot objects on any furniture surface. Always use a hot plate or placemat. Laminate and lacquer finishes on table tops provide added scratch and heat resistance to our furniture, but they can still be damaged without proper care
- Avoid exposing your furniture to strong sunlight, heat outlet, open windows or dampness. Prolonged exposure to direct sunlight can fade the finish of your furniture, while extreme temperature and humidity changes can cause cracking or splitting
- Do not expose your furniture to any liquids. Never allow water to sit on your furniture. Alcohol, nail polish and perfume are also dangerous as they will dissolve the lacquer finish on contact and may require professional repairs
- Do not allow plastic to come in direct contact with your furniture. Chemicals in the plastic of placemats etc. may soften and mark the finish if left in contact with the furniture for a period of time

Product Care for Fabric Items

REGULAR CARE:

- Protect from direct sunlight
- Vacuum regularly using low suction
- Rotate reversible cushions regularly
- Avoid exposure to new clothing, cushions or throws as this may lead to dye transfer and permanent staining

CLEANING:

- Do not remove cushion covers for separate cleaning even though they may have zippers
- Do not wash, Do not dry clean, Do not shampoo clean
- Clean only with hot water extraction machine. Professional cleaning recommended
- Do not use dishwashing liquid or laundry detergent. Use only upholstery detergents
- Do not wet filling
- Dry in shade away from direct heat and sunlight
- Allow to dry thoroughly before re-use

SPOT CLEANING:

- Do not rub
- Do not spot clean with any solvent
- Treat spills and stains as soon as possible
- Gently scrape off any soil or blot any liquid from the surface of the fabric before applying cleaner
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill
- Do not saturate the fabric or interior with water or other cleaning liquids

WARNING:

Apply only water-based soil resist (fabric protection) treatments. Do not use aerosol products

* PILLING IS NOT A FABRIC DEFECT OR FAULT AND IS NOT COVERED BY WARRANTY

* PILLING IS A NORMAL OCCURRENCE IN WOVEN FABRICS AND DOES NOT AFFECT THE DURABILITY OR FUNCTIONALITY OF THE FABRIC. IT IS EASILY REMOVED BY USE OF A BATTERY OPERATED DE-PILLING MACHINE AS THE NEED ARISES