




**ASSEMBLY INSTRUCTION  
KERID DINING TABLE  
ITEM CODE 86760**





Imported by Amart Furniture Pty Ltd. Qld. Brisbane Australia.

For any assistance with assembly or for missing parts please phone Amart Furniture Customer Service Free call 1800 351 084

# PRE-ASSEMBLY PREPARATION

## Before you start:

1. Choose a clean, level, spacious assembly area. Avoid hard surfaces that may damage the product
2. Take care when lifting. Product should be assembled as near as possible to the point of use
3. Ensure that you have all required contents for complete assembly.
4. Always read the assembly instructions carefully before beginning assembly.
5. Keep all hardware parts and packaging out of reach of small children.
6. Do not over tighten the screws and bolts as this may damage the threads

 <p>ALLOW 30 MINUTES</p>	 <p>2 PEOPLE REQUIRED</p>
 <p>ADDITIONAL TOOLS REQUIRED</p>	



# CAM Lock and Pins

## step 1

### HOW TO USE CAM LOCK FASTENERS

To assemble this product hardware called Cam Lock Fasteners are used. The below is information on how these work.

Cam Locks are fasteners used to join two boards together, usually the edge of one board(A) to the flat side of another board(B)




Ensure that you use the correct images that are representative of the hardware used in the product

## step 2

### To use Cam Lock Fasteners

The Cam Pin is inserted into the flat side of a board, it is important that:


- \* The cam pin is kept vertical and is not put in on an angle
- \* Cam Pin is inserted up to the collar
  - \* Too far and it wont catch the Cam Lock (Do not Over Tighten)
  - \* Not enough and the resulting product wont be stable



## step 3

### To use Cam Lock Fasteners


Now fit the hole in the edge of the joining board over the Cam Pin



## step 4


### To use Cam Lock Fasteners

The Head of the Cam Pin will be visible in the large hole on the side of the joining board



## To use Cam Lock Fasteners

Notice the Cam Lock has a "C" Shaped back An Arrow or +/- signs on the front, indicated the open section on the back of the Cam Pin




Cam Lock

## step 5

### To use Cam Lock Fasteners


In sert the Cam Lock into the large hole so the opening of the "C" fits over the head of the Cam Pin.You must ensure that the Cam Lock is pushed to the bottom of the hole to catch the top of the Cam Pin




## step 6

### To use Cam Lock Fasteners


Use a flat screwdriver to turn the Cam Lock clockwise one half a turn so it Locks onto the head of the Cam Pin.Turn only until it is snug-over-tightening could cause the Cam to bend or break. If it will not turn the full amount,turn the Cam Pin out (counter-clockwise)one full turn,and try the Cam Lock again.



# PARTS LIST




C1	Top Panel
C2x2	Long Vertical Post
C3x2	Short Vertical Brace
C4	Center Cross Bracing
C5x2	Leg
C6x2	Leg


<input type="checkbox"/> A.Cam lock and Cam pin Ø15X35  18PCS	<input type="checkbox"/> B.Dowel Ø10x50  24PCS	<input type="checkbox"/> C.Protect foam Ø35X5mm  8PCS	<input type="checkbox"/> D.Bolt M8x80  12PCS	<input type="checkbox"/> E.Half Round Nuts M8  12PCS	<input type="checkbox"/> F.Hexagonal Nuts M8  12PCS	<input type="checkbox"/> G.Cover Ø38  12PCS
<input type="checkbox"/> H.Wrench M14  1PCE	<input type="checkbox"/> I.GLUE  1PCE					

**86760**

Step 1: Use Phillips Head Screwdriver to insert the Cam Pin(A) to the Panel (C1,C2). Insert Dowel(B) to the Panel(C2,C3,C5,C6) . Insert Bolt(D) to the Panel(C1,C5,C6) .




Step 2: Use Wrench(J) to assemble the Panel(C2,C3) to the Footboard(C5,C6) with Bolt(D) and Half Round Nut(E) and Hexagonal Nut(F), Insert the Cover(G) to the holes. Use a Phillips Head Screwdriver to assemble Panel (C4) to the Panel(C2) with Cam Lock(A).




86760

Step 3: Use Wrench(J) to assemble the Panel(C5,C6) to the Footboard(C1) with Bolt(D) and Half Round Nut(E) and Hexagonal Nut(F), Insert the Cover(G) to the holes. Use a Phillips Head Screwdriver to assemble Panel (C2,C3,C4) to the Panel(C1) with Cam Lock(A). Attach Protect Foam(C) to Panel (C5,C6).



Assembly is complete.



DO NOT PUSH OR DRAG THIS TABLE-In doing so, damage may be caused to the base.  
Do not sit or lean on the edge of the table. By doing so the table may tip to one side.

# General Product Care

To protect your furniture, we suggest the following:

- Avoid placing your furniture in direct sunlight.
- Do not place furniture directly under windows.
- Do not place sharp materials (knife, fork, etc.) directly onto your furniture as sharp material may scrape and damage the finish.
- Do not place material with high temperature directly onto the surface of your furniture.
- Clean up spills quickly. Water left over a prolonged period of time may cause damage. Alcohol, perfume, nail polishes, aftershave and some medication may cause severe finish damage if not cleaned immediately.
- Use a clean, soft, dry, lint free absorbent cloth to clean your furniture. Do not use any detergent as they may contain ingredients that may react and damage the finish.